

User's Setup Guide, T6000 Series

1







Diagram illustrating the unboxing of the printer. The printer is shown next to its cardboard box, with a red arrow indicating the box is being opened. A USB cable and a roll of paper are also shown.



Three diagrams showing the printer from different perspectives: front view, top view, and side view, with red arrows indicating the location of the paper tray and the top cover.

2




Diagram showing a roll of paper and a roll of ribbon, with red arrows pointing to the corresponding components in the printer.

Загрузка бумаги/риббона






Diagram illustrating the paper loading process. The top cover is open, and the paper tray is shown. A red arrow points to the paper tray. Below, a diagram shows the ribbon cartridge being inserted into the printer. A red arrow points to the ribbon cartridge. At the bottom, a diagram shows the ribbon path through the printer, with red arrows indicating the direction of the ribbon.

3




Diagram showing a USB cable and a power button, with a red arrow pointing to the power button.

Подключение






Diagram illustrating the connection process. A red arrow points to the power cord being plugged into the printer. Below, a diagram shows the USB cable being plugged into the printer's USB port. A red arrow points to the USB port. At the bottom, a diagram shows the power button being pressed, with a red arrow pointing to the power button.

4




Diagram showing a magic wand, with a red arrow pointing to the printer screen.

Пуск




Diagram illustrating the printer's setup wizard. The top screen shows the 'Printer Setup WIZARD' menu with language options: English, Italiano, 简体中文, Deutsch, Español, 繁體中文, Français, Português, 한국어. Below the screen, a red arrow points down to the bottom screen, which displays 'Printer Setup Wizard Completed!' and 'Your changes have been saved to Config 1, now the Power-Up Config.' Below the bottom screen, a red arrow points to the power button.

5




QR code linking to the printer's website.


www.PrintronixAutoID.com



Драйверы



Инструкция



Видео по эксплуатации